



- 00. 영사선 (ZERO LINE)
- 01. 영상미로 (PICTURE BATTEN)
- 02. 코터 (CONTIGUOUS CURTAIN)
- 03. 코터 1 (# 1 DRAW CURTAIN)
- 04. 장치물 1 + 미러막 1 (# 1 SET BATTEN + # 1 HOUSE BORDER)
- 05. 조명물 1 (# 1 LIGHT BATTEN)
- 06. 장치물 2 (# 2 SET BATTEN)
- 07. 장치물 3 (# 3 SET BATTEN)
- 08. 다린막 1, 2 (# 1, 2 HOUSE LEG)
- 09. 천장투광미러막 1 (# 1 ACOUSTICAL SHELL - CEILING)
- 10.11. 측면투광미러막 1, 2 (# 1, 2 ACOUSTICAL SHELL - SIDE WALL)
- 12. 장치물 4 (# 4 SET BATTEN)
- 13. 조명물 2 (# 2 LIGHT BATTEN)
- 14. 영사막 + 가림막 (SCREEN + COVER CURTAIN)
- 15. 광막 2 (# 2 DRAW CURTAIN)
- 16. 장치물 5 (# 5 SET BATTEN)
- 17. 장치물 6 (# 6 SET BATTEN)
- 18. 장치물 7 + 미러막 3 (# 7 SET BATTEN + # 3 HOUSE BORDER)
- 19. 조명물 3 (# 3 LIGHT BATTEN)
- 20. 다린막 3, 4 (# 3, 4 HOUSE LEG)
- 21.23. 천장투광미러막 2 (# 2 ACOUSTICAL SHELL - CEILING)
- 22.24. 측면투광미러막 2 (# 2 ACOUSTICAL SHELL - SIDE WALL)
- 25. 장치물 8 (# 8 SET BATTEN)
- 26. 조명물 4 (# 4 LIGHT BATTEN)
- 27. 후면투광미러막 (ACOUSTICAL SHELL - BACK WALL)
- 28. 하늘미러막 + 미러막 4 (SKY CYC. LIGHT + # 4 HOUSE BORDER)
- 29. 장치물 10 (# 10 SET BATTEN)
- 30. 하늘막 (CYCLOPAMA)